

## AeroTect Bumper Plugs Installation

**Contents included:**

Bumper Plugs

**Other Items that you may need:**Drill with ¼ inch drill bit  
Or ¼ inch Phillips screw driver  
Razor or exacto knife

Thank you for choosing AeroTect® brand Products. If you have any question about your installation, please call us at (909) 596-0053 or e-mail us at [info@erotect.net](mailto:info@erotect.net).

1. Clean area thoroughly.
2. Hole sizes may vary. Our plugs are designed to fit in ¼" hole. It is a good idea to bore out your hole with a ¼" screwdriver to remove loose debris inside the hole. If your hole is too small, you may need to drill your hole to the correct size.
3. If you have excess plastic surrounding your hole, you will need to trim and remove it. Use an exacto or razor knife until the hole is flush with the bumper.
4. To install, simply press your AeroTect brand Bumper Plugs into the hole.

