

AeroTect Door Edge Guard Protection - Installation Instructions

Contents included:

4 pieces of 34" door edge guard
1 Applicator squeegee

Other items that might be helpful:

Scissors, razor knife, or exacto knife
Microfiber towel.

Thank you for choosing AeroTect® brand Products. If you have any question about your installation, please call us at (909) 596-0053 or e-mail us at info@erotect.net.

1. Clean area to be applied thoroughly. Use your alcohol solution to remove any wax or grease that may be on surface.

2. Door edge is to be applied dry. Start by peeling back the first inch of the door edge film, and align to the top of the door edge. Slowly peel the film and tack down so that about 1/2 of the door edge width is on the outside of the door, with the other half hanging over the edge.

2. It helps to wet your thumb to avoid friction as you tack the film down. Continue toward the bottom stretching the film slightly and tacking down as you go. Curved doors may require a little more stretching or work.

4. Once your film is tacked down, you may need to trim your film to your desired ending location if the door edge guard is too long. You can use scissors, a razor knife, or an exacto knife to do so.

5. Start wrapping the film around the edges starting from the outside portion that is tacked down to ensure that you won't trap any air on the edges. Using your thumbs to curl the film over typically works best for this.

