

## AeroTect Fog Lamp Installation

**Contents included:**Fog Lamps  
Applicator squeegee**Other Items you will need for wet application only:**Mixture of 4 drops baby shampoo with 1 quart of water in spray bottle  
Lint free towel**Optional items you may need:**

Heat gun or hair dryer

Thank you for choosing AeroTect® brand Products. If you have any question about your installation, please call us at (909) 596-0053 or e-mail us at [info@erotect.net](mailto:info@erotect.net).

1. Clean area to be applied thoroughly. Be sure to remove all grease, wax, and dirt. Perform the installation in a controlled and clean environment.

**Dry Application**

Peel film approximately 3 inches away from backing. **Do Not** touch adhesive side of the film. Center and align the peeled portion of the film with the edge of the light. Apply pressure with your fingers to tack down the edge. Using a sweeping motion, slowly begin to apply pressure with the applicator while you peel the backing from the film. Continue until the full fog light is covered.

**Wet Application**

Spray your hands/fingers, the adhesive side of the film, and the fog light with your soap/water mixture. Center and align the film on the light. With a sweeping motion use the provided applicator to squeegee out all water and air bubbles. Dry around the edges with a lint free towel

- If you find the film is too stiff to work with you can soften with a heat gun or hair dryer.
- Small air bubbles will disappear over time as the film settles.
- Wax the film quarterly with a carnauba wax for UV protection

