

AeroTect Headlamp Protective Film Installation

Contents included:

Headlamp Protective Film
Applicator squeegee

Other Items you will need:

Mixture of 15 oz. water and 1 oz. 70% Isopropyl alcohol in a
spray bottle
Paper towels

Other items that may be helpful:

Heat gun or hair dryer

Thank you for choosing AeroTect® brand Products. If you have any question about your installation, please call us at (909) 596-0053 or e-mail us at info@erotect.net.

1. Clean headlamps thoroughly. Be sure to remove all grease, wax and dirt. Perform installation in a controlled and clean environment. Handle the kit only on the edges prior to the installation. Be careful not to touch the adhesive side of the film.

2. Spray your hands/fingers and adhesive side of the film with your water/alcohol solution. Center and align the film on the light

3. Align and tack down the inner corner of the film by using your applicator and a downward sweeping motion. Continue to use your applicator in a sweeping motion while you gently stretch the film up and around on the light. A heat gun or hair dryer is recommended for medium to large applications especially those with curves. A heat gun may be used during this step, be cautious not to over heat the film.

4. Use your applicator to squeegee out all water and air bubbles. Dry around the edges with a lint free towel.

- Small bubbles and pockets of moisture will disappear over time as film settles.
- Wax the film quarterly with a carnauba wax for UV protection

