

AeroTect IS 250/350 CF B-Pillar Overlay - Installation Instructions

Contents included:

8 pieces of Carbon Fiber Overlay
1 Applicator squeegee

Other items that you may need:

Hair dryer or heat gun
Microfiber towel
Razor Knife

Thank you for choosing AeroTect® brand Products. If you have any question about your installation, please call us at (909) 596-0053 or e-mail us at info@aerotect.net.

1. Clean area to be applied thoroughly. Use your alcohol solution to remove any wax or grease that may be on surface. Film is to be applied to dry surface.

2. Line your first piece up starting at the bottom (allowing for a slight overhang of the film on sides of the center pieces).

3. Use your Applicator Squeegee to tack down the film a couple inches at a time. Make sure your piece is still centered as you work up.

4. Use a hair dryer or heat gun on the edges of the film, being careful not to overheat the film, and tack down all edges. If your film has extended past the top of the B-Pillars, use a razor knife to trim the excess right in the groove at the top of the B-Pillar.

5. Using your heat gun or hair dryer, warm up the outside edges of the film, and begin wrapping the film around the sides. It usually helps to wrap with your thumb, and then use the applicator squeegee for a couple passes.

The Mirror section and small rear window strip won't wrap around the sides, but it is still a good idea to heat up the edges and firmly tack down the film

