

AeroTect IS 250/350 CF Interior Trim Overlays - Installation Instructions

Contents included:

7 pieces of Carbon Fiber Overlay
1 Applicator squeegee
1 Razor Knife

Other items that you may need:

Hair dryer or heat gun
Microfiber towel

Thank you for choosing AeroTect® brand Products. If you have any question about your installation, please call us at (909) 596-0053 or e-mail us at info@erotect.net.

1. Clean area to be applied thoroughly. Use your alcohol solution to remove any wax or grease that may be on surface. Film is to be applied to dry surface.

2. First you will need to remove all of your trim pieces that will be covered from your vehicle. Once removed from your vehicle, you will need to remove all the components such as door lock, and window controls from the trim piece. There are several resources on the web regarding how to do this, however if you are unsure that you can handle such an operation, you should have a professional do this work for you.

Clean all trim pieces thoroughly before applying.

3. Pick your first piece and align around any openings. A second set of hands might help, but is not necessary.

Once aligned, begin tacking the film down with your applicator, starting around any cutouts/openings. Continue tacking until the entire face of the piece is covered. You will need to continually adjust the film as you work. Make sure the main surface is tacked down before worrying about wrapping the films edges.

4. To wrap the film around the edges, Being careful not to overheat the film, use a heat gun or hair dryer to soften the film, and slowly work the film around the edges with your fingers. Some corners may require a slight stretch to reduce folds/creases in the film.

Don't get frustrated if you have a few extra ripples or creases on these wrapped edges. Edges such as the outside area of the door trim pieces will be hidden once re-installed.

5. Trim the excess film by resting the blades flat side on the edges of the trim piece, and shave the excess film off. This will need to be done to both the outer edges and the control openings where any film is hanging over the edge.

Reinstall your trim pieces and enjoy the new look of your IS!

