

AeroTect Red out instruction – 2006-2008 Lexus IS

Contents included:

Red outs
Applicator Squeegee

Other Items you will need:

Spray bottle with water and 3 drops baby shampoo
Paper Towels

Optional items that may be useful:

Heat gun or hair dryer

Thank you for choosing AeroTect® brand Products. If you have any question about your installation, please call us at (909) 596-0053 or e-mail us at info@erotect.net.

1. Clean area of application thoroughly. Make sure the lights are clean and free of all dust and dirt.

2. Spray taillight and adhesive side of film with water/soap mixture. Be sure not to touch the adhesive side of the film, doing so may leave fingerprints.

3. Align and center the film on the amber portion of the taillight. Make adjustments while the film is wet.

4. Apply pressure with the squeegee to remove all water and air bubbles from underneath the film. Press and dry any ripples with a paper towel. If installing in cold weather use a hair dryer to flatten the ripples.

