

AeroTect Red out instruction – 2009 Lexus IS 250/350

Contents included:

Red outs (the kit includes 2 extra corner pieces if needed)
Applicator Squeegee

Other Items you will need:

Spray bottle with water and 3 drops baby shampoo
Paper Towels or detailing cloth

Other Items that may be helpful:

Hair dryer or heat gun

Thank you for choosing AeroTect® brand Products. If you have any question about your installation, please call us at (909) 596-0053 or e-mail us at info@erotect.net.

1. Clean area of application thoroughly. Make sure lights are clean and free of all dust and dirt.
2. Start with the large piece first. Spray the light and adhesive side of the film with the soap/water mixture. Be sure not to touch the adhesive side of the film, as this may leave finger prints. Center the red out over the amber portion of the taillight. Remove all water and bubbles from underneath the film with the squeegee.
3. Dry the edges with a cloth or paper towel. (It is very important that edges are perfectly dry before applying the corner pieces.)
4. Apply the corner pieces dry. Tack 1 inch of the corner piece down starting from the top. Tack the corner piece downwards 1 inch at a time making sure to align the seams perfectly. Stretch the film gently as you press the film down. If air bubbles occur lift that section and re-apply.
5. Press on all of the edges with your squeegee to ensure pieces are tacked down and not peeling (paying special attention to the seams). If available, use a hair dryer or heat gun on low to dry all your edges. Be careful not to overheat the film or light cover.

