

AeroTect Lexus Console Protection Kit

Contents included:Console Protection Film
squeegee**Other Items you will need:**Spray bottle with water and 4 drops baby shampoo
Paper towels or detailing cloth

Thank you for choosing AeroTect® brand Products. If you have any questions about your installation, please call us at (909) 596-0053 or e-mail us at info@erotect.net.

1. Clean area to be applied thoroughly. Using a damp towel with Isopropyl alcohol will remove all grease and dust.
2. Using your soap/water solution spray the adhesive side of the film while removing it from the backing. This will allow you to easily maneuver the film when it is placed on the console. Be careful not to touch the back of the film.
3. Place the film on the console and align to desired coverage area.
4. Spray a few drops of soapy solution on the surface of the film. This will allow the squeegee to slide freely across the surface. Start applying pressure with the squeegee to remove all excess water from under the film. Keep a paper towel next to you to clean excess water and keep the console dry.
5. Ensure all of the edges and corners are tacked down, and dry any remaining water off of the console.

